

# FIREPROOFING BEST PRACTICES

Read specifications to job

Job start (hand off)

Mandatory job walk; no hangers straps, all threads, no obstructions, and needs poured decks above

Order equipment

Review with foreman and superintendent

Meet with inspector to review process

SWIPP setup-diagram 2

Pump setup-build rolling scaffold, stand pipe, hang tarps, and mix alum

Protection-cover sprinkler pipes, elevator rails and equipment

Pre check pump-run pump/mix

Check cup weights - very important (refer to manufacturer instructions)

Check beam thickness chart

Start spraying

Check thicknesses (repeat gauging throughout operation)

Clean; scrap floors, remove protection, and remove all debris

Sign off floor with the general contractor - take pictures of the clean floor area