

Best practices

PLASTERING/ STUCCO

Check specifications to the job

Vetting meetings, materials

Job start (hand off) budget-materials-schedules

Mandatory job walk- before start date-preplan

Order equipment-materials-manpower

Review cost codes and budget

Review pump procedures

Plaster pump setup

SWIPP-setup-diagram 1

Pump silo placement; very important for hose lengths. Try not to exceed 500 ft. from silo to wall.

Gun Hose stretch-line out –Prepare for direction of shoot

Protection (cover) ground windows and doors, rooftops and balconies

Run pump-pump the sponge; protect from packing thru cleanliness

Should have at least 1000 yds. of lath ready and completed

Apply scratch coat

Moist cure-48 hours typical

Apply brown coat

Clean scaffold of all sand and cement rubble

Moist cure-2 days typical

Skim if acrylic or color prime

Apply finish coat

Remove protection from windows, roofs, and reveals

Clean scaffold of all debris and rubble to prepare for tear down